
| maxon motor control | EPOS2 Positioning Controller |
|---------------------|------------------------------|
| Cable Starting Set | Edition December 2013 |

EPOS2 24/2

Positioning Controller

Cable Starting Set



Document ID: rel4255

PLEASE READ THIS FIRST



Theseinstructions are intended for qualified technical personnel. Prior commencing with any activities

- ..
- · you must carefully read and understand this manual and
- you must follow the instructions given therein.

We have tried to provide you with all information necessary to install and commission the equipment in a **secure**, **safe** and **time-saving** manner. Our main focus is ...

- · to familiarize you with all relevant technical aspects,
- · to let you know the easiest way of doing,
- to alert you of any possibly dangerous situation you might encounter or that you might cause if you do not follow the description,
- to write as little and to say as much as possible and
- · not to bore you with things you already know.

Likewise, we tried to skip repetitive information! Thus, you will find things **mentioned just once**. If, for example, an earlier mentioned action fits other occasions you then will be directed to that text passage with a respective reference.



Followany stated reference - observer espective information - then go back and continue with the task!

PREREQUISITES FOR PERMISSION TO COMMENCE INSTALLATION

The EPOS2 24/2 is considered as partly completed machinery according to EU's directive 2006/42/EC, Article 2, Clause (g) and therefore is intended to be incorporated into or assembled with other machinery or other partly completed machinery or equipment.



You must not put the device into service, ...

- unless you have made completely sure that the other machinery the surrounding system the device
 is intended to be incorporated to fully complies with the requirements stated in the EU directive
 2006/42/EC!
- unless the surrounding system fulfills all relevant health and safety aspects!
- unless all respective interfaces have been established and fulfill the stated requirements!

TABLE OF CONTENTS

| 1 | About this Do | ocument | 5 |
|---|---------------|---|----|
| 2 | Introduction | | 8 |
| | 2.1 | Documentation Structure | 8 |
| | 2.2 | Safety Precautions | 9 |
| 3 | Cables | | 10 |
| | 3.1 | Important Notice: Prerequisites for Permission to commence Installation | 10 |
| | 3.2 | Tools | 10 |
| | 3.3 | Cable Selector | 11 |
| | 3.4 | Cable Assemblies | 12 |
| | | 3.4.1 Encoder Cable (275934) – Connector J3 | 12 |
| | | 3.4.2 Encoder Cable (275934) – Connector J9 | 14 |
| | | 3.4.3 Motor/Hall Sensor Cable (302948) – Connector J10 | 16 |
| | | 3.4.4 DC Motor Cable (303490) – Connector J10 | 18 |
| | | 3.4.5 Encoder Cable (275934) – Connector J11 | 19 |
| | | 3.4.6 RS232-COM Cable (275900) – Connector J12 | 21 |
| | | 3.4.7 CAN-COM Cable (275908) – Connector J13 | 22 |
| | | 3.4.8 CAN-CAN Cable (275926) – Connector J13 | 23 |
| | | 3.4.9 CAN-Y Cable (319471) – Connector J13 | 24 |
| | | 3.4.10 Signal Cable 16core (275932) – Connector J14 | 25 |
| | | 3.4.11 USB Type A - mini B Cable (370513) - Connector J15 | 27 |
| | 3.5 | FPOS2 24/2 Connector Set (303807) | 28 |

••page intentionally left blank••

1 About this Document

1.1 Intended Purpose

The purpose of the present document is to familiarize you with the described equipment and the tasks on safe and adequate installation and/or commissioning.

Observing the described instructions in this document will help you ...

- · to avoid dangerous situations,
- · to keep installation and/or commissioning time at a minimum and
- to increase reliability and service life of the described equipment.

Use for other and/or additional purposes is not permitted. maxon motor, the manufacturer of the equipment described, does not assume any liability for loss or damage that may arise from any other and/or additional use than the intended purpose.

1.2 Target Audience

This document is meant for trained and skilled personnel working with the equipment described. It conveys information on how to understand and fulfill the respective work and duties.

This document is a reference book. It does require particular knowledge and expertise specific to the equipment described.

1.3 How to use

Take note of the following notations and codes which will be used throughout the document.

| Notation | Explanation |
|----------|--|
| (n) | referring to an item (such as order number, list item, etc.) |
| → | denotes "see", "see also", "take note of" or "go to" |

Table 1-1 Notations used in this Document

1.4 Symbols and Signs

1.4.1 Safety Alerts



Take note of when and why the alerts will be used and what the consequences are if you should fail to observe them!

Safety alerts are composed of...

- · a signal word,
- · a description of type and/or source of the danger,
- the consequence if the alert is being ignored, and
- · explanations on how to avoid the hazard.

Following types will be used:

1) DANGER

Indicates an **imminently hazardous situation**. If not avoided, the situation will result in death or serious injury.

2) WARNING

Indicates a **potentially hazardous situation**. If not avoided, the situation **can** result in death or serious injury.

3) CAUTION

Indicates a **probable hazardous situation** and is also used to alert against unsafe practices. If not avoided, the situation **may** result in minor or moderate injury.

Example:



DANGER

High Voltage and/or Electrical Shock

Touching live wires causes death or serious injuries!

- Make sure that neither end of cable is connected to life power!
- Make sure that power source cannot be engaged while work is in process!
- Obey lock-out/tag-out procedures!
- Make sure to securely lock any power engaging equipment against unintentional engagement and tag with your name!

1.4.2 Prohibited Actions and Mandatory Actions

The signs define prohibitive actions. So, you must not!

Examples:



Do not touch!



Do not operate!

The signs point out actions to avoid a hazard. So, you must!

Examples:



Unplug!



Tag before work!

1.4.3 Informatory Signs



Requirement / Note / Remark

Indicates an action you must perform prior continuing or refers to information on a particular item.



Best Practice

Gives advice on the easiest and best way to proceed.



Material Damage

Points out information particular to potential damage of equipment.



Reference

Refers to particular information provided by other parties.

1.5 Trademarks and Brand Names

For easier legibility, registered brand names are listed below and will not be further tagged with their respective trademark. It must be understood that the brands (the below list is not necessarily concluding) are protected by copyright and/or other intellectual property rights even if their legal trademarks are omitted in the later course of this document.

| The brand name(s) | is/are a registered trademark(s) of |
|-----------------------------|-------------------------------------|
| Micro-Fit™ Mini-Fit Jr.™ | © Molex, USA-Lisle, IL |

Table 1-2 Brand Names and Trademark Owners

1.6 Copyright

© 2013 maxon motor. All rights reserved.

The present document – including all parts thereof – is protected by copyright. Any use (including reproduction, translation, microfilming and other means of electronic data processing) beyond the narrow restrictions of the copyright law without the prior approval of maxon motor ag, is not permitted and subject to persecution under the applicable law.

maxon motor ag

Brünigstrasse 220 P.O.Box 263 CH-6072 Sachseln Switzerland

Phone +41 41 666 15 00 Fax +41 41 666 16 50

www.maxonmotor.com

2 Introduction

The present document provides you with information on the wiring details for each cable which will be used with the EPOS2 24/2 hardware. It contains pictures, drawings, cable specification, pin assignment and detailed connector information. The included «Cable Selector» will help you to choose the correct cable for the setup you are using.

The EPOS2 24/2 Positioning Controller is available in different variants possessing an identical basic setup, however, their individual configuration varies slightly. The present document covers the entire scope on all variants, thus providing you with all relevant information regardless of the actual type of controller you are using.

Find the latest edition of the present document, as well as additional documentation and software to the EPOS2 24/2 Positioning Controller also on the internet: →www.maxonmotor.com

2.1 **Documentation Structure**

The present document is part of a documentation set. Please find below an overview on the documentation hierarchy and the interrelationship of its individual parts:




Figure 2-1 **Documentation Structure**

© 2013 maxon motor. Subject to change without prior notice.

2.2 Safety Precautions

Prior continuing ...

- make sure you have read and understood chapter "PLEASE READ THIS FIRST" on page A-2,
- do not engage with any work unless you possess the stated skills (→chapter "1.2 Target Audience" on page 1-5),
- refer to chapter "1.4 Symbols and Signs" on page 1-5 to understand the subsequently used indicators,
- you must observe any regulation applicable in the country and/or at the site of implementation
 with regard to health and safety/accident prevention and/or environmental protection,
- take note of the subsequently used indicators and follow them at all times.



DANGER

High Voltage and/or Electrical Shock

Touching live wires causes death or serious injuries!

- Consider any power cable as connected to life power, unless having proven the opposite!
- Make sure that neither end of cable is connected to life power!
- Make sure that power source cannot be engaged while work is in process!
- Obey lock-out/tag-out procedures!
- Make sure to securely lock any power engaging equipment against unintentional engagement and tag with your name!



Requirements

- Make sure that all associated devices and components are installed according to local regulations.
- Be aware that, by principle, an electronic apparatus can not be considered fail-safe. Therefore, you
 must make sure that any machine/apparatus has been fitted with independent monitoring and safety
 equipment. If the machine/apparatus should break down, if it is operated incorrectly, if the control unit
 breaks down or if the cables break or get disconnected, etc., the complete drive system must return –
 and be kept in a safe operating mode.
- Be aware that you are not entitled to perform any repair on components supplied by maxon motor.



Electrostatic Sensitive Device (ESD)

- Make sure to wear working cloth in compliance with ESD.
- · Handle device with extra care.

Cables

Important Notice: Prerequisites for Permission to commence Installation

3 Cables

3.1 Important Notice: Prerequisites for Permission to commence Installation

The EPOS2 24/2 is considered as partly completed machinery according to EU's directive 2006/42/EC, Article 2, Clause (g) and therefore is only intended to be incorporated into or assembled with other machinery or other partly completed machinery or equipment.



WARNING

Risk of Injury

Operating the device without the full compliance of the surrounding system with the EU directive 2006/42/EC may cause serious injuries!

- Do not operate the device, unless you have made sure that the other machinery fulfills the requirements stated in EU's directive!
- Do not operate the device, unless the surrounding system fulfills all relevant health and safety aspects!
- Do not operate the device, unless all respective interfaces have been established and fulfill the stated requirements!

3.2 Tools

If you should decide not to use the ready-made cable assemblies, we strongly recommenced to employ the following hand tools.

| Tools | | | | | | |
|---------|---------------------------------|--|--|--|--|--|
| Crimper | Molex hand crimper (63819-0000) | | | | | |
| Chimper | Molex hand crimper (63819-0900) | | | | | |

Table 3-3 Recommended Tools

3.3 Cable Selector

Use the following table to find the matching cables for the maxon motor variant and type of equipment you will be using:

| Cable | | EPOS2 24/2 | | | | | | Communication | | |
|-------------------------------------|--------|------------|---|--|---------------------------------------|---|---|---------------|-------|-----|
| | | | 390438 | 380264 | 390003 | | | Communication | | |
| Designation | Order# | Connector | DC motor with integrated motor/encoder ribbon cable | EC motor with integrated motor/Hall sensor cable | DC motor with separated encoder cable | DC motor with integrated motor/encoder ribbon cable | EC motor with separated Hall sensor & encoder cables | USB | RS232 | CAN |
| | | J3 | 0 | | | | | | | |
| Encoder Cable | 275934 | J9 | | 0 | | | | | | |
| | | J11 | | | 0 | 0 | 0 | | | |
| Motor/Hall Sensor Cable | 302948 | J10 | | | | | Х | | | |
| DC Motor Cable | 303490 | J10 | | | Х | | | | | |
| Signal Cable 16core | 275932 | J14 | | | Х | Х | Х | | | |
| RS232-COM Cable | 275900 | J12 | | | 0 | 0 | 0 | | Х | |
| CAN-COM Cable | 275908 | J13 | | | 0 | 0 | 0 | | | Х |
| CAN-CAN Cable | 275926 | J13 | | | 0 | 0 | 0 | | | 0 |
| CAN-Y Cable | 319471 | J13 | | | 0 | 0 | 0 | | | 0 |
| USB Type A - mini B Cable | 370513 | J15 | Х | Х | Х | Х | Х | Х | | |
| Legend: X = required / O = optional | | | | | | | | | | |

Cable Selector

Table 3-4

3.4 Cable Assemblies

3.4.1 Encoder Cable (275934) – Connector J3



Figure 3-2 Encoder Cable

| Technical Data | | | | | | | |
|---------------------|---|--|--|--|--|--|--|
| Cable cross-section | 10 x AWG28, round-jacket, twisted pair flat cable, pitch 1.27 mm | | | | | | |
| Length | 3.20 m | | | | | | |
| Head A | DIN 41651 female connector, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |
| Head B | DIN 41651 Plug, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |

Table 3-5 Encoder Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|--------|---------------|---------------|-----------------|-----------------|------------------------|
| brown | 1 | 1 | 1 | Motor+ | Motor terminal "+" |
| white | 2 | 2 | | +5 VDC / 100 mA | Encoder supply voltage |
| red | 3 | 3 | 2 | GND | Ground |
| white | 4 | 4 | 2 | Motor- | Motor terminal "-" |
| orange | 5 | 5 | 3 | Channel A\ | Channel A complement |
| white | 6 | 6 | 3 | Channel A | Channel A |
| yellow | 7 | 7 | 4 | Channel B\ | Channel B complement |
| white | 8 | 8 | 4 | Channel B | Channel B |
| green | 9 | 9 | 5 | Channel I\ | Index complement |
| white | 10 | 10 | 3 | Channel I | Index |

Table 3-6 Encoder Cable – Pin Assignment, J3



Note

Encoder Cable head B. The pin out suits, for example:

• maxon digital MR Encoder type M, S (all with Line Driver)

3.4.2 Encoder Cable (275934) - Connector J9



Figure 3-3 Encoder Cable

| Technical Data | | | | | | | |
|---------------------|---|--|--|--|--|--|--|
| Cable cross-section | 10 x AWG28, round-jacket, twisted pair flat cable, pitch 1.27 mm | | | | | | |
| Length | 3.20 m | | | | | | |
| Head A | DIN 41651 female connector, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |
| Head B | DIN 41651 Plug, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |

Table 3-7 Encoder Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|--------|---------------|---------------|-----------------|-----------------|------------------------|
| brown | 1 | 1 | 1 | not connected | _ |
| white | 2 | 2 | | +5 VDC / 100 mA | Encoder supply voltage |
| red | 3 | 3 | 2 | GND | Ground |
| white | 4 | 4 | 2 | not connected | - |
| orange | 5 | 5 | 3 | Channel A\ | Channel A complement |
| white | 6 | 6 | 3 | Channel A | Channel A |
| yellow | 7 | 7 | 4 | Channel B\ | Channel B complement |
| white | 8 | 8 | 4 | Channel B | Channel B |
| green | 9 | 9 | 5 | Channel I\ | Index complement |
| white | 10 | 10 | 3 | Channel I | Index |

Table 3-8 Encoder Cable – Pin Assignment, J9



Note

Encoder Cable head B. The pin out suits, for example:

- maxon digital MR-Encoder type L, M, ML (all with Line Driver)
- maxon digital encoder HEDL 55_ (with Line Driver RS422)

3.4.3 Motor/Hall Sensor Cable (302948) – Connector J10

Head A Head B



Figure 3-4 Motor/Hall Sensor Cable

| Technical Data | | | | | | | |
|---------------------|---|--|--|--|--|--|--|
| Cable cross-section | Cable 1: 1 x 3 x 0.25 mm ² , shielded Cable 2: 1 x 5 x 0.14 mm ² , shielded | | | | | | |
| Length | 3 m | | | | | | |
| Head A | Molex Micro-Fit 3.0 8 poles (430-25-0800) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) Cable lug Ø3.2 mm (for M3 screws) | | | | | | |
| Head B | Cable end sleeves 0.25 mm ² Cable end sleeves 0.14 mm ² | | | | | | |

Table 3-9 Motor/Hall Sensor Cable – Technical Data

DC Motor

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|---------|---------------|---------------|-----------------|---------------|--------------------|
| white2 | 1 | | _ | not connected | |
| brown2 | 2 | | _ | not connected | - |
| green1 | 3 | | _ | not connected | _ |
| white1 | 4 | | _ | Motor+ | Motor terminal "+" |
| grey2 | 5 | | _ | not connected | - |
| green2 | 6 | | _ | not connected | _ |
| yellow2 | 7 | | _ | not connected | _ |
| brown1 | 8 | | _ | Motor- | Motor terminal "-" |

Table 3-10 Motor/Hall Sensor Cable – Pin Assignment (DC Motor), J10

EC Motor

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|---------|---------------|---------------|-----------------|--|---------------------|
| white2 | 1 | | _ | Hall sensor 3 | Hall sensor 3 input |
| brown2 | 2 | | _ | Hall sensor 2 | Hall sensor 2 input |
| green1 | 3 | | _ | Motor winding 3 Winding 3 | |
| white1 | 4 | | _ | Motor winding 1 | Winding 1 |
| grey2 | 5 | | _ | +V _{Hall} Hall sensor supply voltage (+5 VDC / 30 mA) | |
| green2 | 6 | | _ | Hall sensor 1 | Hall sensor 1 input |
| yellow2 | 7 | | _ | GND | Ground |
| brown1 | 8 | | _ | Motor winding 2 | Winding 2 |

Table 3-11 Motor/Hall Sensor Cable – Pin Assignment (EC Motor), J10

3.4.4 DC Motor Cable (303490) - Connector J10



Figure 3-5 Motor/Hall Sensor Cable

| | Technical Data | | | | | | |
|---------------------|---|--|--|--|--|--|--|
| Cable cross-section | 2 x 0.25 mm ² , shielded | | | | | | |
| Length | 3 m | | | | | | |
| Head A | Molex Micro-Fit 3.0 8 poles (430-25-0800) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) Cable lug Ø3.2 mm (for M3 screws) | | | | | | |
| Head B | Cable end sleeves 0.25 mm ² | | | | | | |

Table 3-12 Motor/Hall Sensor Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description | |
|--------|---------------|---------------|--------------|---------------------------|--------------------|--|
| white | 1 | | _ | not connected | _ | |
| brown | 2 | | _ | not connected | - | |
| green | 3 | | _ | not connected | - | |
| white | 4 | | _ | Motor+ | Motor terminal "+" | |
| grey | 5 | | _ | not connected | - | |
| green | 6 | | _ | not connected | - | |
| yellow | 7 | | _ | not connected | - | |
| brown | 8 | | _ | Motor- Motor terminal "-" | | |

Table 3-13 Motor/Hall Sensor Cable – Pin Assignment, J10

3.4.5 Encoder Cable (275934) - Connector J11



Figure 3-6 Encoder Cable

| Technical Data | | | | | | | |
|---------------------|---|--|--|--|--|--|--|
| Cable cross-section | 10 x AWG28, round-jacket, twisted pair flat cable, pitch 1.27 mm | | | | | | |
| Length | 3.20 m | | | | | | |
| Head A | DIN 41651 female connector, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |
| Head B | DIN 41651 Plug, pitch 2.54 mm, 10 poles, plug strain relief | | | | | | |

Table 3-14 Encoder Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|--------|---------------|---------------|-----------------|-----------------|------------------------|
| brown | 1 | 1 | 1 | Motor+ | Motor terminal "+" |
| white | 2 | 2 | ' | +5 VDC / 100 mA | Encoder supply voltage |
| red | 3 | 3 | 2 | GND | Ground |
| white | 4 | 4 | 2 | Motor- | Motor terminal "-" |
| orange | 5 | 5 | 3 | Channel A\ | Channel A complement |
| white | 6 | 6 | 3 | Channel A | Channel A |
| yellow | 7 | 7 | 4 | Channel B\ | Channel B complement |
| white | 8 | 8 | 4 | Channel B | Channel B |
| green | 9 | 9 | 5 | Channel I\ | Index complement |
| white | 10 | 10 | 3 | Channel I | Index |

Table 3-15 Encoder Cable – Pin Assignment, J11



Note

Encoder Cable head B. The pin out suits, for example:

• maxon digital MR Encoder type M, S (all with Line Driver)

3.4.6 RS232-COM Cable (275900) – Connector J12



Figure 3-7 RS232-COM Cable

| Technical Data | | | | | | | |
|---------------------|--|--|--|--|--|--|--|
| Cable cross-section | 2 x 2 x 0.14 mm ² , twisted pair, shielded | | | | | | |
| Length | 3 m | | | | | | |
| Head A | Molex Micro-Fit 3.0 6 poles (430-25-0600) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) | | | | | | |
| Head B | Female D-Sub connector DIN 41652, 9 poles, with mounting screws | | | | | | |

Table 3-16 RS232-COM Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description | |
|--|---------------|---------------|-----------------|----------|---------------------|--|
| yellow | 1 | 3 | 1 | EPOS RxD | EPOS RS232 receive | |
| white | 2 | 2 | 2 | EPOS TxD | EPOS RS232 transmit | |
| green | 4 | 5 | 1 | GND | RS232 ground | |
| brown | 5 | 5 | 2 | GND | RS232 ground | |
| black | 6 | _ | _ | Shield | Cable shield | |
| - Housing - Shield Cable shield, soldered to connector housing | | | | | | |
| Remark: pin assignment according to RS232 Standard | | | | | | |

Table 3-17 RS232-COM Cable – Pin Assignment, J12

3.4.7 CAN-COM Cable (275908) – Connector J13



Technical Data

Cable cross-section 2 x 2 x 0.14 mm², twisted pair, shielded

Length 3 m

Head A Molex Micro-Fit 3.0 4 poles (430-25-0400)
Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx)

Head B Female D-Sub connector DIN 41652, 9 poles, with mounting screws

Table 3-18 CAN-COM Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|---|---------------|---------------|-----------------|------------|-------------------|
| yellow | 1 | 7 | 1 | CAN high | CAN high bus line |
| green | 2 | 2 | ' | CAN low | CAN low bus line |
| brown | 3 | 3 | _ | CAN GND | CAN ground |
| black | 4 | 5 | _ | CAN shield | Cable shield |
| Remark: pin assignment according to CiA DS102-2 | | | | | |

Table 3-19 CAN-COM Cable – Pin Assignment, J13

3.4.8 CAN-CAN Cable (275926) - Connector J13



Figure 3-9 CAN-CAN Cable

| Technical Data | | | | | | | |
|---------------------|--|--|--|--|--|--|--|
| Cable cross-section | 2 x 2 x 0.14 mm ² , twisted pair, shielded | | | | | | |
| Length | 3 m | | | | | | |
| Head A / Head B | Molex Micro-Fit 3.0 4 poles (430-25-0400) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) | | | | | | |

Table 3-20 CAN-CAN Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|--------|---------------|---------------|-----------------|------------|-------------------|
| yellow | 1 | 1 | 1 | CAN high | CAN high bus line |
| green | 2 | 2 | • | CAN low | CAN low bus line |
| brown | 3 | 3 | _ | CAN GND | CAN ground |
| black | 4 | 4 | - | CAN shield | Cable shield |

Table 3-21 CAN-CAN Cable – Pin Assignment, J13

3.4.9 CAN-Y Cable (319471) - Connector J13

Head A Head B







Figure 3-10 CAN-Y Cable

| Technical Data | | | | | | |
|---------------------|--|--|--|--|--|--|
| Cable cross-section | 2 x 4 x 0.14 mm ² , single wires | | | | | |
| Length | 0.05 m | | | | | |
| Head A / Head B | Molex Micro-Fit 3.0 4 poles (430-25-0401) Molex Micro-Fit 3.0 male crimp terminals (43031-xxxx) | | | | | |
| Head C | Molex Micro-Fit 3.0 4 poles (430-25-0400) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) | | | | | |

Table 3-22 CAN-Y Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Head C Pin | Twisted Pair | Signal | Description |
|--------|---------------|---------------|---------------|-----------------|------------|-------------------|
| yellow | 2 | 2 | 1 | _ | CAN high | CAN high bus line |
| green | 1 | 1 | 2 | 1 | CAN low | CAN low bus line |
| brown | 4 | 4 | 3 | _ | CAN GND | CAN ground |
| black | 3 | 3 | 4 | _ | CAN shield | Cable shield |

Table 3-23 CAN-Y Cable – Pin Assignment, J13



Note

The CAN-Y Cable fits the other CAN cables.

3.4.10 Signal Cable 16core (275932) - Connector J14



Figure 3-11 Signal Cable 16core

| Technical Data | | | | |
|---------------------|--|--|--|--|
| Cable cross-section | 16 x 0.14 mm ² | | | |
| Length | 3 m | | | |
| Head A | Molex Micro-Fit 3.0 16 poles (430-25-1600) Molex Micro-Fit 3.0 female crimp terminals (43030-xxxx) | | | |
| Head B | Cable end sleeves 0.14 mm ² | | | |

Table 3-24 Signal Cable 16core – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description | |
|------------------|---------------|---------------|--------------|-----------|--|--|
| white | 1 | | _ | D_Gnd | Digital signal ground | |
| brown | 2 | | _ | D_Gnd | Digital signal ground | |
| green | 3 | | _ | DigIN6 | Digital input 6 "Negative Limit Switch" | |
| yellow | 4 | | _ | DigIN5 | Digital input 5 "Positive Limit Switch" | |
| grey | 5 | | _ | DigIN4 | Digital input 4 "Home Switch" | |
| pink | 6 | | _ | DigIN3 | Digital input 3 "General Purpose" | |
| blue | 7 | | _ | DigIN2 | Digital input 2 "General Purpose" | |
| red | 8 | | _ | DigIN1 | Digital input 1 "General Purpose" | |
| black | 9 | | _ | +VOUT | Auxiliary supply voltage Output (+5 VDC / 10 mA) | |
| violet | 10 | | _ | DigOUT4 | Digital output 4 "General Purpose" | |
| grey/ pink | 11 | | _ | DigOUT3 | Digital output 3 "General Purpose" | |
| red/blue | 12 | | - | +VCC | Power supply voltage (+924 VDC) | |
| white/ green | 13 | | _ | Power_Gnd | Power ground | |
| brown/ green | 14 | | _ | A_Gnd | Analog signal ground | |
| white/ yellow | 15 | | _ | AnIN2 | Analog Input 2 | |
| yellow/ brown | 16 | | _ | AnIN1 | Analog Input 1 | |

Table 3-25 Signal Cable 16core – Pin Assignment, J14

3.4.11 USB Type A - mini B Cable (370513) - Connector J15

Head A Head B



Figure 3-12 USB Type A - mini B Cable

| Technical Data | | | | |
|---------------------|---|--|--|--|
| Cable cross-section | 1 x 28 AWG non-twisted power pair / 1 x 28 AWG twisted data pair, aluminum-metallized polyester inner shield, 28 AWG stranded tinned copper drain wire, > 65%, tinned copper wire interwoven (braided) outer shield, PVC jacket | | | |
| Length | 3 m | | | |
| Head A | USB Type mini B, male | | | |
| Head B | USB Type A, male | | | |

Table 3-26 USB Type A - mini B Cable – Technical Data

| Wire | Head A Pin | Head B Pin | Twisted Pair | Signal | Description |
|---------|---------------|---------------|-----------------|------------------|---|
| red | 1 | 1 | _ | V _{BUS} | USB BUS supply voltage input +5 VDC |
| white | 2 | 2 | 1 | D- | USB Data- |
| green | 3 | 3 | ' | D+ | USB Data+ |
| _ | 4 | _ | _ | ID | not connected |
| black | 5 | 4 | _ | GND | USB_Ground |
| Jacket | Shield | Shield | _ | Cable shield | Cable shield, soldered to connector housing |
| Remark: | | | | <u> </u> | |

pin assignment according to USB 2.0 standard

Table 3-27 USB Type A - mini B Cable – Pin Assignment, J15

Cables EPOS2 24/2 Connector Set (303807)

3.5 EPOS2 24/2 Connector Set (303807)

If you decide not to use the ready-made cable assemblies, you can take advantage of a prepackaged set containing all required connectors. The set contains following items:

| Connector | Specification | Quantity |
|-----------|--|----------|
| J10 | Molex Micro-Fit 3.0 8 poles (430-25-0800) | 1 |
| J12 | Molex Micro-Fit 3.0 6 poles (430-25-0600) | 1 |
| J13 | Molex Micro-Fit 3.0 4 poles (430-25-0400) | 1 |
| J14 | Molex Micro-Fit 3.0 16 poles (430-25-1600) | 1 |
| | Molex Micro-Fit 3.0 female crimp terminal (43030-0010) | 40 |
| | Tyco C42334-A421-C42 (right), encoder clip right | 1 |
| | Tyco C42334-A421-C52 (left), encoder clip left | 1 |

Table 3-28 EPOS2 24/2 Connector Set – Content



Best Practice

For best results use original manufacturer's tools (→chapter "3.2 Tools" on page 3-10).

LIST OF FIGURES

| Figure 2-1 | Documentation Structure | 8 |
|-------------|---------------------------|----|
| Figure 3-2 | Encoder Cable | 12 |
| Figure 3-3 | Encoder Cable | 14 |
| Figure 3-4 | Motor/Hall Sensor Cable | 16 |
| Figure 3-5 | Motor/Hall Sensor Cable | 18 |
| Figure 3-6 | Encoder Cable | 19 |
| Figure 3-7 | RS232-COM Cable | 21 |
| Figure 3-8 | CAN-COM Cable | |
| Figure 3-9 | CAN-CAN Cable | 23 |
| Figure 3-10 | CAN-Y Cable | 24 |
| Figure 3-11 | Signal Cable 16core | 25 |
| Figure 3-12 | USB Type A - mini B Cable | 27 |

LIST OF TABLES

| Table 1-1 | Notations used in this Document | 5 |
|------------|--|----|
| Table 1-2 | Brand Names and Trademark Owners | 7 |
| Table 3-3 | Recommended Tools | 10 |
| Table 3-4 | Cable Selector | 11 |
| Table 3-5 | Encoder Cable – Technical Data | 12 |
| Table 3-6 | Encoder Cable – Pin Assignment, J3 | 13 |
| Table 3-7 | Encoder Cable – Technical Data | 14 |
| Table 3-8 | Encoder Cable – Pin Assignment, J9 | 15 |
| Table 3-9 | Motor/Hall Sensor Cable – Technical Data | 16 |
| Table 3-10 | Motor/Hall Sensor Cable – Pin Assignment (DC Motor), J10 | 16 |
| Table 3-11 | Motor/Hall Sensor Cable – Pin Assignment (EC Motor), J10 | 17 |
| Table 3-12 | Motor/Hall Sensor Cable – Technical Data | 18 |
| Table 3-13 | Motor/Hall Sensor Cable – Pin Assignment, J10 | 18 |
| Table 3-14 | Encoder Cable – Technical Data | 19 |
| Table 3-15 | Encoder Cable – Pin Assignment, J11 | 20 |
| Table 3-16 | RS232-COM Cable – Technical Data | 21 |
| Table 3-17 | RS232-COM Cable – Pin Assignment, J12 | 21 |
| Table 3-18 | CAN-COM Cable – Technical Data | 22 |
| Table 3-19 | CAN-COM Cable – Pin Assignment, J13 | 22 |
| Table 3-20 | CAN-CAN Cable – Technical Data | 23 |
| Table 3-21 | CAN-CAN Cable – Pin Assignment, J13 | 23 |
| Table 3-22 | CAN-Y Cable – Technical Data | 24 |
| Table 3-23 | CAN-Y Cable – Pin Assignment, J13 | 24 |
| Table 3-24 | Signal Cable 16core – Technical Data | 25 |
| Table 3-25 | Signal Cable 16core – Pin Assignment, J14 | 26 |
| Table 3-26 | USB Type A - mini B Cable – Technical Data | 27 |
| Table 3-27 | USB Type A - mini B Cable – Pin Assignment, J15 | 27 |
| Table 3-28 | EPOS2 24/2 Connector Set – Content | 28 |

••page intentionally left blank••

© 2013 maxon motor. All rights reserved.

The present document – including all parts thereof – is protected by copyright. Any use (including reproduction, translation, microfilming and other means of electronic data processing) beyond the narrow restrictions of the copyright law without the prior approval of maxon motor ag, is not permitted and subject to persecution under the applicable law.

maxon motor ag

Brünigstrasse 220 P.O.Box 263 CH-6072 Sachseln Switzerland

Phone +41 41 666 15 00 Fax +41 41 666 16 50

www.maxonmotor.com